


**AMGO**  **Hydraulics**

Original

# Installation And Service Manual



**FOUR-POST LIFT**  
**Model: 408-HP**

# CONTENTS

Product Features and Specifications ..... 1

Installation Requirement ..... 2

Steps of Installation ..... 4

Exploded View ..... 24

Test Run .....32

Operation Instruction .....33

Maintenance .....34

Trouble Shooting .....35

Lift Disposal.....35

# I. PRODUCT FEATURES AND SPECIFICATIONS

## 4-POST MODEL 408-HP FEATURES

- Single cylinder drive and transmission by cable
- Single point manual safety release, more convenient and reliable for decent operation.
- Four mechanical locking devices, each equipped with both primary and secondly safety locks.
- Power-side column can be installed at both side, front or rear.
- Non-skid diamond platforms and adjustable safety lock ladders.
- Optional kits: Rolling jack, caster kits.




Fig. 1

## MODEL 408-HP SPECIFICATIONS

| Model  | Lifting Capacity   | Lifting Height    | Lifting Time | Overall Length (Inc. Ramps) | Overall Width      | Overall Height    | Width Between Columns | Motor                      |
|--------|--------------------|-------------------|--------------|-----------------------------|--------------------|-------------------|-----------------------|----------------------------|
| 408-HP | 8,000lbs<br>3500KG | 87 5/8"<br>2227mm | 83S<br>38S   | 207"<br>5257mm              | 109 5/8"<br>2784mm | 96 5/8"<br>2455mm | 96 "<br>2438mm        | 110V: 1.0HP<br>220V: 2.0HP |

## II. INSTALLATION REQUIREMENT

### A. TOOLS REQUIRED

- ✓ Tape Measure (7.5m)



- ✓ Hammer



- ✓ Level Bar



- ✓ English Spanner (12")



- ✓ Wrench set  
(12#, 13#, 14#, 15#, 17#, 19#, 24#, 30#)



- ✓ Carpenter's Chalk



- ✓ Screw Sets



- ✓ Pliers



- ✓ Lock Wrench



- ✓ Socket Head Wrench  
(3#, 5#, 6#, 8#)



Fig. 2

**B. Equipment storage and installation requirements.**

The equipment should be stored or installed in a shady, normal temperature, ventilated and dry place.

**C. The equipment should be unload and transfer by forklift.**




**Fig.3**

**D. SPECIFICATIONS OF CONCRETE (See Fig. 4)**

Specifications of concrete must be adhered to the specification as following.

**Failure to do so may result in lift and/or vehicle falling.**

1. Concrete must be thickness 4"(100mm) minimum and without reinforcing steel bars, and must be dried completely before the installation.
2. Concrete must be in good condition and must be of test strength 3,000psi (210kg/cm<sup>2</sup>) minimum.
3. Floors must be level and no cracks.



**Fig. 4**

**E. POWER SUPPLY**

The electrical source must be 3.0HP. The source cable size must be 2.5mm<sup>2</sup> and in good condition of contacting with floor.

### III. STEPS OF INSTALLATION

#### A. Check the parts before assembly

1. Packaged lift and Hydraulic Power Unit (See Fig. 5).



Fig. 5

Oil tray (Optional)

2. Open the outer packing carefully, check the parts according to the shipment list. (See Fig. 6).




Fig. 6

3. Take off the drive-in ramps and columns (See Fig.7 ).




Fig. 7

4. Loose the screws of the upper package stand, take off the offside platform, take out the parts inside the power-side platform, then remove the package stand.

5. Move aside the parts and check the parts according to the shipment parts list(See Fig. 8).



Fig.8

6. Open the carton of parts and check the parts according to the parts box list (See Fig. 9).



Fig. 9

7. Check the parts of the parts bag according to the parts bag list (See Fig. 10).



Fig. 10

B. Use a carpenter's chalk line to establish installation layout as per Fig.11. Make sure the size is right and base is flat (see Fig. 11).  
 Note: Reserve space front and behind the installation site.





Fig.11


| MODEL  | A                    | B                    | C                |
|--------|----------------------|----------------------|------------------|
| 408-HP | 4400mm<br>(173 1/4") | 2784mm<br>(109 5/8") | 5207mm<br>(205") |



**C. Install cross beams. The cross beam opening towards inside, the power-side column need to be installed close to the rotational safety device. (See Fig.12, Fig.13).**




**Fig.12**



**Fig.13**


## D. Install the Safety Ladders.

1. Take off the pulley safety cover and unscrew a nut of the safety ladders, and then adjust the four lower nuts to be at the same position. Then install the safety ladder (See Fig. 14).




**Fig.14**

2. Install Safety Ladders (See Fig. 15).




Safety ladder pass through the hole of the top plate, then tighten the two nuts.

**E. Put the cross beams to the same height and lock at the safety ladder (See Fig. 16).**



## F. Install power-side platform.

1. Install the power-side platform on the cross beams by a fork lift or manual, offset the cross beams to outside a little until the pulleys of both platforms enter into the cross beams opening (**See Fig.17**). Aligning holes on the power-side platform and cross beam, then screw up the bolts.




2. Install tire stop plate with bolts and washer on the platform: Tighten the platform on cross beam B with bolts, tighten the tire stop plate on cross beam A with bolt.


**Note:** The bolts for the side with tire stop plate are longer than the side without tire stop plate, pay attention when choosing the bolts (**See Fig.18**)

**Instruction:** 1). This lift both ends can drive the car in(cross beam **A** and **B**), user can install the lift according to the location. The following method of installation is driving the car in from the cross beam **B**, if choosing the cross beam **A** to drive the car in then install the tire stop plate to the other end.

2) . The Power-side column can be installed at cross beam **A** or **B**, but the power unit must be installed the same direction with the safety lock release handle.



**G. Install offside platform and limit block, then install the bolts for the platform strengthen plate, check the plumbness of columns with level and adjusting with the shims (See Fig. 19).**




Position the slide blocks along the bent edges of the columns. Connect the slide blocks to the cross beam with bolts.

**Note: DO NOT** completely tighten the limit slide blocks. Loosen 1/4 lap after tightening.

**Fig. 19**


## H. Illustration for cable installation

1. The cables pass through the platform to the columns according to the number of the cables (See Fig. 20).



| NO.                               | ①      | ②       | ③      | ④      |
|-----------------------------------|--------|---------|--------|--------|
| Cable Length (inc. cable fitting) | 5011mm | 10789mm | 6390mm | 9400mm |


2. The cable goes through the cross beam to top plate of columns and be screwed with cable nuts (**See Fig. 21**).




**Fig. 21**



3. Illustration for platform cables (See Fig. 22).




**I. Install connecting bar for safety device and release handle (See Fig. 23).**



**Fig. 23**


Pass the connecting bar through middle of the rotational safety device of cross beam **A/B**

Rotate and adjust the connecting bar, aligning the connecting holes in the rotational safety device and release handle on cross beam **A**, then tighten with socket bolts (M8\*35) and lock washers.



Install extend lock release handle and plastic ball

Safety lock rotated Device




Rotate and adjust another connecting bar, then aligning the holes in the rotational safety device of cross beam **B**, then tighten with socket bolts (M8\*35) and lock washers.

## J. Install power unit, articulated casing tube

**Note:** Power unit must be installed the same side as the safety release handle.


1. Install Power unit on the cross beam **A**, the installation of Connection tube is as **Fig.24**



Install socket bolt (M8\*25) with lock washer to these two holes. (Connect the connecting bar and articulated casing tube)

**Fig. 24**

2. Diagram of installation for articulated casing tube when power unit on the cross beam B.  
(See Fig.25)




**Fig. 25**

## K. Install Hydraulic System

1. For power unit install to the column at the side of cross beam **A** (See Fig. 26)


**Note:** Oil hoses connected to oil cylinder must be passed above the cable to avoid the oil hose scratched by cable.



**Fig. 26**

2. For power unit install to the column at the side of cross beam **B** (See Fig. 27).

**Note:** The length of oil return hose can be cut short as required.



**Fig. 27**



## L. Install Electrical System

Connect the power source on the data plate of Motor.

- Note: 1. For the safety of operators, the power wiring must contact the floor well.  
 2. Pay attention to the direction of rotations when using 380V, three phase motors.


### Single phase motor

1. Connecting the two power supply wire (fire wire **L** and zero wire **N**) to terminals of AC contactor marked **L1, L3** respectively.
2. Connecting the two motor wires to terminals of AC contactor marked **T1, T3**.
3. Connecting **A1** to **L3** of AC contactor.
4. Connecting the two wires of the button switch to the terminals of AC contactor marked **A2, L1**.



**Fig. 28**


**M. Install spring and safety cover of cross beam (See Fig. 29).**



**Fig.29**

**N. Install drive-in ramp, jack tray and plastic oil tray (See Fig. 30).**

According to the below diagram screw up the bolts (M16\*30), then install the drive-in ramp.



**Fig. 30**

## O. Install Rear wheel stop plates (See Fig. 31)

After the vehicle is on the lift, take off the drive-in ramp, replace with rear wheel stop plates.




Fig. 31

## P. Installation of optional kits.

1. Install caster kits or Rolling jack (See Fig. 32)





Fig. 32




| Item | Part#     | Description            | QTY. |
|------|-----------|------------------------|------|
| 73-1 | 11410042A | Support bracket        | 4    |
| 73-2 | 10209125  | Hex bolt M10*30        | 16   |
| 73-3 | 10209039  | φ10 Lock washer        | 16   |
| 73-4 | 10209022  | φ10 Washer             | 16   |
| 73-5 | 10209021  | Hex nut M10            | 16   |
| 73-6 | 10410035  | Universal wheel(6")    | 4    |
| 73-7 | 11410034  | Connecting pin φ19*216 | 4    |
| 73-8 | 10209012  | Hair Pin φ3.2          | 8    |

2. Install optional motor fixing bracket (See Fig. 33 & 34).




Motor fixing bracket on cross beam **A**  
**Fig. 33**



Motor fixing bracket on cross beam **B**  
**Fig. 34**

**Q. Install the anchor bolts.**


1. Prepare the anchor bolts (See Fig. 35).



**Fig. 35**

2. Check the plumbness of columns with leveling instrument and adjusting with the shims. Using the prescribed rotary hammer drill, and drill all the anchor holes and install the anchor bolts. Do not tighten the anchor bolts (See Fig. 36).


Note: The tightening torque for the anchor bolt is 150N.m ,Anchor bolts driven into the ground at least 3 1/2"(90mm).



**Fig. 36**


## IV. EXPLODED VIEW

### Model 408-HP



**Fig. 37**

# EXPLODED VIEW of Power-side platform



**Fig. 38**

## PARTS LIST FOR MODEL 408-HP

| Item | Part#          | Description                             | 408-HP | NOTE |
|------|----------------|---|--------|------|
| 1    | 11410074-01    | Power-side Column                       | 1      |      |
| 2    | 11410075-01    | Offside Column                          | 3      |      |
| 3    | 11410003-01    | Cross Beam A                            | 1      |      |
| 4    | 11410004       | Offside Platform                        | 1      |      |
| 5    | 1104533001A    | Power-side Platform                     | 1      |      |
| 6    | 11410006-01    | Cross Beam B                            | 1      |      |
| 7    | 11410007       | Drive-in ramp                           | 2      |      |
| 8    | 10209043       | Hex Bolt M8*20                          | 6      |      |
| 9    | 10209033       | Washer $\phi$ 8                         | 32     |      |
| 10   | 10209005       | Self locking Nut                        | 26     |      |
| 11   | 11420012A      | Cylinder fixed ring                     | 1      |      |
| 12   | 1004536000     | Cylinder $\phi$ 80*1041                 | 1      |      |
| 13   | 1104533013A-01 | Piston rod connecting seat              | 1      |      |
| 14   | 10410012       | Hex Nut M24                             | 1      |      |
| 15   | 10201005       | Split Pin $\phi$ 4*50                   | 1      |      |
| 16   | 071103         | Manual power unit                       | 1      |      |
| 17   | 10420175A      | Hex nut M20                             | 16     |      |
| 18   | 11410073-01    | Safety ladder L=2324                    | 4      |      |
| 19   | 1101533012A    | Pulley pin $\phi$ 35*96.5               | 4      |      |
| 20   | 10420023A      | Washer $\phi$ 36* $\phi$ 65*3           | 13     |      |
| 21   | 11420024B      | Pulley                                  | 6      |      |
| 21A  | 10530042       | Bush bronze $\phi$ 41.3* $\phi$ 35.1*28 | 6      |      |
| 21B  | 1104533023     | Dual-Slots Pulley $\phi$ 190*30         | 2      |      |
| 22   | 10209034       | Lock washer $\phi$ 8                    | 16     |      |
| 23   | 10420144       | Washer $\phi$ 8* $\phi$ 25*3            | 4      |      |
| 24   | 10410013       | Hex Bolt M16*30                         | 8      |      |
| 25   | 10420137       | Lock washer $\phi$ 16                   | 8      |      |
| 26   | 10420029       | Washer $\phi$ 16                        | 8      |      |
| 27   | 10410014       | Hex Bolt M16*35                         | 4      |      |
| 28   | 11410116-1     | Tire stop plate                         | 2      |      |
| 29   | 10206006       | Washer $\phi$ 12                        | 12     |      |
| 30   | 10420026       | Lock washer $\phi$ 12                   | 8      |      |
| 31   | 10410105       | Hex Bolt M12*20                         | 8      |      |
| 32   | 10410016A      | Slide block 81*38*38mm                  | 16     |      |
| 33   | 10410017       | Socket bolt M8*40                       | 18     |      |
| 34   | 10201090       | Shim(2mm)                               | 20     |      |
|      | 10620065       | Shim(1mm)                               | 20     |      |
| 35   | 1004505003     | Cable 1 9.52*5011mm                     | 1      |      |
| 36   | 1004505004     | Cable 2 9.52*10789mm                    | 1      |      |
| 37   | 1004505002     | Cable 3 9.52*6390mm                     | 1      |      |
| 38   | 1004505001     | Cable 4 9.52*9400mm                     | 1      |      |
| 39   | 10650502       | Socket Bolt M10*100                     | 1      |      |
| 40   | 11410023       | Connecting bar $\phi$ 19*2060mm         | 2      |      |
| 41   | 11410024       | Articulated casing tube                 | 1      |      |
| 42   | 10209032       | Socket bolt M8*25                       | 4      |      |

| Item                  | Part#          | Description  | 408-HP | NOTE |
|-----------------------|----------------|--|--------|------|
| 43                    | 10217005       | Plastic ball M10                                     | 1      |      |
| 43A                   | 10209056       | Self locking Nut M10                                 | 1      |      |
| 44                    | 10410025       | Socket bolt M8*35                                    | 4      |      |
| 45                    | 11410026       | Safety release handle                                | 1      |      |
| 45A                   | 11410100       | Extension release handle                             | 1      |      |
| 46                    | 10209004       | Rubber ring φ8*φ20*3                                 | 4      |      |
| 47                    | 10209003       | Hex Bolt M8*25                                       | 8      |      |
| 48                    | 10420166       | 90° Fitting  | 1      |      |
| 49                    | 10420119       | Straight Fitting for cylinder<br>1/4JIC(M)*3/8NPT(M) | 1      |      |
| 50                    | 1004533005     | Oil hose 1/4*2569mm                                  | 1      |      |
| 51                    | 10420120       | Extended straight fitting with nut                   | 1      |      |
| 52                    | 10207026       | Oil hose 1/4*1520mm                                  | 1      |      |
| 53                    | 10209060       | 90° Fitting for power unit                           | 1      |      |
| 54                    | 10420095       | Straight fitting                                     | 1      |      |
| 55                    | 10410028       | Oil return hose L=5500mm                             | 1      |      |
| 56                    | 10410036       | Protective hose φ20*1*1500mm                         | 1      |      |
| 57                    | 10209145A      | Cup head bolt with washer M6*12                      | 8      |      |
| 58                    | 10410029       | Plastic cover for cross beam                         | 4      |      |
| 59                    | 10410146       | Spring φ14*2.0*75                                    | 4      |      |
| 60                    | 10420033       | Spring φ14*1.8*100                                   | 4      |      |
| 61                    | 10209059       | Anchor bolt 3/4*5-1/2                                | 16     |      |
| 62                    | 10410500A      | Parts box  | 1      |      |
| 63                    | 11410094       | Tyre stop plate                                      | 2      |      |
| 64                    | 1004533006     | Slider 106*49*40                                     | 1      |      |
| 64A                   | 85090332       | Socket bolt M10*70                                   | 1      |      |
| 65                    | 1104533013A-01 | Piston rod connecting seat                           | 1      |      |
| 66                    | 10481005       | Wash φ30   | 2      |      |
| 67                    | 1104533017A-01 | Pulley pin φ25*77.5                                  | 2      |      |
| 68                    | 1104533024     | Cushion tube φ40*23                                  | 2      |      |
| 69                    | 1104533020     | Pulley adjustment sleeve φ45*5*23                    | 1      |      |
| 70                    | 1104533011     | Pulley φ167*16                                       | 4      |      |
| 70A                   | 1004542002     | Bronze bush φ36*φ30.1*15                             | 4      |      |
| 71                    | 10201002       | Hex bolt M8*16                                       | 2      |      |
| <b>Optional Parts</b> |                |  |        |      |
| 72                    | 11410040       | Jack tray  | 1      |      |
| 73                    | 1040801        | Caster kit   | 4      |      |
| 74                    | 96600002       | Rolling Jack J5H                                     | 1      |      |
| 75                    | 1140802B       | Motor fixing plate                                   | 1      |      |
| 76                    | 10410039       | Oil tray   | 4      |      |

#### 4.1 CYLINDERS EXPLODED VIEW (1004536000)





Fig. 39


| Item  | Part#       | Description   | 408-HP | Note |
|-------|-------------|---------------|--------|------|
| 12-1  | 10420059    | Dust Ring     | 1      |      |
| 12-2  | 10420060    | Y- Ring       | 1      |      |
| 12-3  | 11420061    | Head Cap      | 1      |      |
| 12-4  | 10420062    | O- Ring       | 1      |      |
| 12-5  | 1004536001A | Bore Weldment | 1      |      |
| 12-6  | 1104536002  | Piston Rod    | 1      |      |
| 12-7  | 11420065    | Pin           | 1      |      |
| 12-8  | 10420066    | Support Ring  | 1      |      |
| 12-9  | 10420067    | Y- Ring       | 1      |      |
| 12-10 | 11420068    | Piston        | 1      |      |

## 4.2 CROSS BEAM EXPLODED VIEW (10410003-01/10410006-01)



| Item | Part#       | Description                              | 408-HP | Note |
|------|-------------|--|--------|------|
| 3-1  | 10206024    | Hex bolt M12*25                          | 4      |      |
| 3-2  | 10206032    | Snap ring $\phi 25$                      | 2      |      |
| 3-2A | 10217020    | Bronze bush $\phi 31 * \phi 25.1 * 16$   | 2      |      |
| 3-3  | 10410099    | Spring $\phi 14 * \phi 2.5 * 100$        | 2      |      |
| 3-4  | 11410031    | Connecting bar for safety lock           | 2      |      |
| 3-5  | 10206023    | Self locking Nut M12                     | 4      |      |
| 3-6  | 11410032-01 | Rotational safety lock device            | 2      |      |
| 3-7  | 11410033-01 | Connecting bar for safety lock           | 2      |      |
| 3-8  | 11420041A   | Pulley Pin $\phi 35 * 105$               | 4      |      |
| 3-9  | 10420132A   | Pulley Bush $\phi 41.3 * \phi 35.1 * 20$ | 10     |      |
| 3-10 | 11420040A   | Pulley pin sleeve $\phi 42 * 3 * 48$     | 4      |      |
| 3-11 | 10209010    | Snap ring $\phi 10$                      | 4      |      |
| 3-12 | 10420035    | Tension pulley                           | 4      |      |
| 3-13 | 11420174    | Spacer $\phi 18 * 4 * 5.5$               | 4      |      |
| 3-14 | 11420171    | Pin $\phi 19 * 98$                       | 12     |      |
| 3-15 | 11420175    | Slack-cable safety lock (Left & Right)   | 2/ea.  |      |
| 3-16 | 11420172    | Pin Bush $\phi 25 * 3 * 31$              | 8      |      |
| 3-17 | 10206019    | Snap ring $\phi 19$                      | 24     |      |
| 3-18 | 10420037    | Snap ring $\phi 16$                      | 16     |      |
| 3-19 | 11420038    | Pin $\phi 16 * 98$                       | 8      |      |
| 3-20 | 10420138    | Socket Bolt M6*16                        | 8      |      |
| 3-21 | 10209149    | Lock washer $\phi 6$                     | 8      |      |
| 3-22 | 10420045    | Washer $\phi 6$                          | 8      |      |
| 3-23 | 11420044    | Limit block                              | 4      |      |

**4.3 Power unit (071103) exploded view:**



**Fig.41**



### Parts list for 110V/60Hz, Single Phase

| Item | Part No. | Description                    | Qty |
|------|----------|--------------------------------|-----|
| 1    | 81400180 | Rubber Pad                     | 2   |
| 2    | 80101034 | Starting capacitor             | 1   |
| 3    | 10420148 | Cup head bolt with washer      | 1   |
| 4    | 81400527 | Protective cover for capacitor | 6   |
| 5    | 81400363 | Motor Connecting Shaft         | 1   |
| 6    | 80101013 | Manifold block                 | 1   |
| 7    | 10209149 | Lock Washer                    | 4   |
| 8    | 81400276 | Iron plug                      | 1   |
| 9    | 81400259 | Red rubber plug                | 1   |
| 10   | 85090142 | Socket bolt                    | 4   |
| 11   | 81400312 | Gear pump                      | 1   |
| 12   | 10209034 | Lock Washer                    | 2   |
| 13   | 81400295 | Socket bolt                    | 2   |
| 14   | 81400365 | O ring                         | 1   |
| 15   | 10209152 | Ties                           | 1   |
| 16   | 85090167 | Magnet                         | 1   |
| 17   | 81400290 | Filter                         | 1   |
| 18   | 81400412 | Steel Motor                    | 1   |
| 19   | 80101035 | Running capacitor              | 1   |
| 20   | 81400530 | Motor terminal box             | 1   |
| 21   | 10420070 | Switch button                  | 1   |
| 22   | 81400559 | AC contactor                   | 1   |
| 23   | 80101039 | America wire and plug          | 1   |
| 24   | 81400528 | Motor terminal box cover       | 1   |
| 25   | 81400560 | Throttle valve                 | 1   |
| 26   | 81400266 | Relief valve                   | 1   |
| 27   | 81400284 | Socket iron plug               | 1   |
| 28   | 81400452 | Hair pin                       | 1   |
| 29   | 81400451 | Release valve handle           | 1   |
| 30   | 10209020 | Plastic ball                   | 1   |
| 31   | 81400421 | Release valve nut              | 1   |
| 32   | 81400422 | Shim                           | 1   |
| 33   | 81400449 | Valve Seat                     | 1   |
| 34   | 81400567 | Release Valve                  | 1   |
| 35   | 80203001 | Check Valve                    | 1   |
| 36   | 81400375 | Oil suction pipe               | 1   |
| 37   | 81400376 | Oil return pipe                | 1   |
| 38   | 81400364 | Clamp                          | 1   |
| 39   | 81400263 | Oil tank cap                   | 1   |
| 40   | 81400275 | Oil tank                       | 1   |

## Illustration of hydraulic valve for power unit




Fig.42

## V. TEST RUN

1. Fill the reservoir with Hydraulic Oil about 6L (**Note:** In consideration of Power Unit's durability, please use **Hydraulic Oil 46#**).
2. Press the control button, the cables will be strained. Check whether the cables match the pulley. Make sure the cables are not across.
3. Press the release valve handle to lock the cross-beam to the safety ladders, and then adjust the platforms to be level by adjusting the nuts of safety ladders.
4. Adjust the cable fitting hex nuts to make platforms and four safety locks work synchronously. You need to run the lift up and down for several times, meanwhile do the synchronous adjustment till the four safety devices can lock and release at the same time.
5. Adjust the clearance between the column and the plastic slider of cross-beam to about 2mm, do not tighten the bolts of the sliding block, let the sliding block can be turned after installing the bolts
6. After finishing the above adjustment, test running the lift with load. Run the lift with platforms in low position first, make sure the platforms can rise and lower synchronously and the safety device can lock and release synchronously. And then test run the lift to the top completely. If there are anything improper, repeat the above adjustment.

## Circuit Diagram of Hydraulic System




Fig.43

## VI. OPERATION INSTRUCTIONS

### To lift vehicle

1. Keep clean of environment near the lift.
2. Drive vehicle to the platform and put on the brake.
3. Take off the drive-in ramp, install rear wheel stop plates to the drive-in ramp position.
4. Turn on the power and press the control button, raise the lift to the working position.

**Note: make sure the vehicle is steady when the lift is raised.**

5. Press the release valve handle to lock the lift in the safety position. Make sure the safety device is locked at the same height.

### To lower vehicle

1. Be sure the clearance of around and under the lift, only leaving operator in lift area.
2. Press the control button, the lift will be raised for 3-5 seconds, and then press the safety release handle, make sure the safety device released, press the release valve handle by the other hand, then the lift starts being lowered automatically.
3. Drive away the vehicle when the lift is lowered to the lowest position. Take off the rear wheel stop plates and install drive-in ramp, then left the lift.
4. Turn off the power.

## **VII. MAINTENANCE SCHEDULE**

### **Monthly:**

1. Lubricate cable with lubricant;
2. Check all cable connection, bolts and pins to insure proper mounting;
3. Make a visual inspection of all hydraulic hoses/lines for possible wear or leakage;
4. Lubricate all rollers, safety devices with 90wt. gear oil or equivalent.

### **Every six months:**

1. Make a visual inspection of all moving parts for possible wear, interference or damage.
2. Check and adjust as necessary, equalizer tension to insure level lifting.
3. Check columns for plumbness.

### **Oil cylinder maintenance:**

In order to extend the service life of the oil cylinder, please operate according to the following requirements.

1. Recommend to use N46 anti-wear hydraulic oil.
2. The hydraulic oil of the lifts should be replaced regularly during using. Replace the hydraulic oil 3 months after the first installation, Replace the hydraulic oil once a year afterwards.
3. Make at least one full trip raising and lowering per day. For exhausting the air from the system, which could effectively avoid the corrosion of the cylinder and damage to the seals caused by presence of air or water in the system.
4. Protect the outer surface of the oil cylinder's piston rod from bumping and scratching, and timely clean up the debris on the oil cylinder dust-ring and the piston rod.

## VIII. TROUBLE SHOOTING

| <b>TROUBLE</b>                        | <b>CAUSE</b>  | <b>REMEDY</b>   |
|---------------------------------------|---|---|
| Motor does not run                    | <ol style="list-style-type: none"> <li>1. Start Button does not work</li> <li>2. Wiring connections are not in good condition</li> <li>3. Motor burned out</li> <li>4. AC contactor burned out</li> </ol>                           | <ol style="list-style-type: none"> <li>1. Replace start button</li> <li>2. Repair all wiring connections</li> <li>3. Repair or replace motor</li> <li>4. Replace AC contactor</li> </ol>    |
| Motor runs but the lift is not raised | <ol style="list-style-type: none"> <li>1. Motor runs in reverse rotation</li> <li>2. Release valve in damage</li> <li>3. Gear pump in damage</li> <li>4. Relief valve or check valve in damage</li> <li>5. Low oil level</li> </ol> | <ol style="list-style-type: none"> <li>1. Reverse two power wire</li> <li>2. Repair or replace</li> <li>3. Repair or replace</li> <li>4. Repair or replace</li> <li>5. Fill tank</li> </ol> |
| Lift does not stay up                 | <ol style="list-style-type: none"> <li>1. Release valve out of work</li> <li>2. Relief valve or check valve leakage.</li> <li>3. Cylinder or fittings leaks</li> </ol>  | Repair or replace   |
| Lift raises too slow                  | <ol style="list-style-type: none"> <li>1. Oil line is jammed</li> <li>2. Motor running on low voltage</li> <li>3. Oil mixed with Air</li> <li>4. Pump leaks</li> <li>5. Overload lifting</li> </ol>                                 | <ol style="list-style-type: none"> <li>1. Clean the oil line</li> <li>2. Check electrical system</li> <li>3. Fill tank</li> <li>4. Repair or replace pump</li> <li>5. Check load</li> </ol> |
| Lift cannot lower                     | <ol style="list-style-type: none"> <li>1. Safety device are not in activated</li> <li>2. Release valve damaged</li> </ol>   | <ol style="list-style-type: none"> <li>1. Operate again</li> <li>2. Repair or replace</li> </ol>  |

## IX. LIFT DISPOSAL:

When the car lift cannot meet the requirements for normal use and needs to be disposed, it should follow local laws and regulations.

## **AMGO HYDRAULIC CORPORATION**

**1931 Joe Rogers Blvd, Manning, South Carolina, USA  
Zip:29102**

**Tel: (803) 505-6410  
fax: (803) 505-6410**

**Manual No.: 72247303  
Revision Date: 2022/10**