

PWB-1530 ASSEMBLY INSTRUCTIONS

- 1) REMOVE WHEEL BALANCER FROM PACKAGING.
- 2) THE LIGHT TRUCK CONE AND SPACER IS USED ON F-350 AND SIMILAR PICK UPS WITH LARGE CENTER HOLE IN RIM.
- 3) INSTALL THE SHAFT ONTO THE BALANCING HUB WITH THE 10MM WRENCH SUPPLIED.
- 4) INSTALL HOOD. TIGHTEN SECURELY.
- 5) INSTALL THE WHEEL BALANCER IN A DRY AREA . TEMPERATURE CHANGES, HUMIDITY, AND CONDENSATION WILL EVENTUALLY CAUSE DAMAGE TO THE ELECTRONICS
- 6) PLACE WHEEL BALANCER ON A FLAT SURFACE . IF YOU DON'T HAVE A FLAT SURFACE, THEN THE WHEEL BALANCER MUST BE SHIMMED , LEVELED AND BOLTED TO THE FLOOR.
- 7) READ AND UNDERSTAND THE OPERATING INSTRUCTIONS.
- 8) PLUG THE POWER CORD INTO A 110V POWER SOURCE. A POWER SURGE PROTECTOR IS RECOMMENDED.
- 9) SWITCH THE YELLOW / RED POWER SWITCH TO THE "ON" POSITION.
- 10) FOLLOW OPERATING INSTRUCTIONS.